





GE
Security

Simon XT
User Manual



P/N 466-2292 REV A ISS 03FEB09

Copyright	<p>© 2009 GE Security, Inc.</p> <p>This document may not be copied in whole or in part or otherwise reproduced without prior written consent from GE Security except where specifically permitted under US and international copyright law.</p> <p>Document number: 466-2292A (February 2009).</p>
Disclaimer	<p>The information in this document is subject to change without notice. GE Security, Inc. ("GE Security") assumes no responsibility for inaccuracies or omissions and specifically disclaims any liabilities, losses, or risks, personal or otherwise, incurred as a consequence, directly or indirectly, of the use or application of any of the contents of this document. For the latest documentation, contact your local supplier or visit us online at www.gesecurity.eu.</p> <p>This publication may contain examples of screen captures and reports used in daily operations. Examples may include fictitious names of individuals and companies. Any similarity to names and addresses of actual businesses or persons is entirely coincidental.</p>
Trademarks and patents	<p>GE and the GE monogram are registered trademarks of General Electric Company.</p> <p>Simon and Simon XT are trademarks of GE Security.</p> <p>Other trade names used in this document may be trademarks or registered trademarks of the manufacturers or vendors of the respective products.</p> <p>This product and the use of this product may be covered by one or more of the following patents: 5,805,063; 5,872,512; 5,942,981; 5,686,896; 5,686,885; or 4,855,713.</p>
Intended use	<p>Use this product only for the purpose it was designed for; refer to the data sheet and user documentation. For the latest product information, contact your local supplier or visit us online at www.gesecurity.eu.</p>
EU directives	<p>2004/108/EC (EMC directive). Non-European manufacturers must designate an authorized representative in the Community. Our authorized manufacturing representative is GE Security, Kelvinstraat 7, 6003 DH Weert, Nederland.</p> <p>1999/5/EC (R&TTE directive). Hereby, GE Security declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.</p> <p> 2002/96/EC (WEEE directive). Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information, visit www.recyclethis.info.</p> <p> 2006/66/EC (battery directive). This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information, visit www.recyclethis.info.</p>
EN 50131-1:2006	<p>Manufacturer: GE Security</p> <p>Description: Intrusion Alarm Control Panel</p> <p>Designed and Manufactured to EN 50131-1:2006</p> <p>Security Grade 2</p> <p>Environmental Class II</p>
Regulatory	<p></p>

Contents

	Preface	v
	Conventions used in this document	v
	Safety terms and symbols	v
Chapter 1.	Introduction	1
	Security system components	2
	Communicating with your system	4
Chapter 2.	Using the control panel	5
	Panel controls	6
	Standard text display	8
	Simon XT features	9
	Things you can do	9
	Home security	9
	Exit/entry delay	10
	Bypassing sensors	12
	Alarms	12
	Light control (optional)	13
	Chimes	13
	Latchkey	14
	System status	14
	Using an offsite phone	15
	Using touchpads	16
	Two-way talking touchpad	16
	Keyfob	17
Chapter 3.	How your system communicates	19
	Alarm sirens and lamp modules	20
	Panel indicator lights	20
	Status beeps	21
	Trouble beeps	21
Chapter 4.	Programming	23
	System menu	24
	Entering and exiting the system menu	24
	Code options	24
	Menu navigation	25
	Top-level menus	27
	Set clock	27
	Set date	28
	Light schedules	28
	Sensor lights	28

Chime.....	28
Special chime.....	28
View event buffer.....	29
System tests.....	29
Revision.....	29
Contrast.....	29
System programming.....	30
Access codes.....	30
Security.....	31
Phone numbers.....	32
Timers.....	32
System options.....	33
Siren options.....	34
Light control.....	36
Ethernet configuration.....	37
GSM configuration.....	37
Chapter 5. Testing.....	39
Testing sensors.....	40
Testing communication.....	41
Appendix A. Reference information.....	43
Alarm system limitations.....	44
Emergency planning.....	45
Smoke and heat detector locations.....	46
Your floorplan.....	47
Sensor and module locations.....	47
Access codes.....	49
Delays.....	49
Battery removal/disposal instructions.....	50
Index.....	53

Preface

This is the *GE Simon XT User Manual*. This document includes an overview of the product and detailed instructions on how to operate the system.

Read these instructions and all ancillary documentation entirely before operating this product. The most current versions of this and related documentation may be found on our online publication library. To access the library, go to our website at the following location:

<http://www.gesecurity.eu>

In the **Customer Support** menu, select the [Resource Library](#) link. After you register and log on, you may search through our online library for the documentation you need.¹

Conventions used in this document

The following conventions are used in this document:

Bold	Menu items and buttons.
<i>Italic</i>	Emphasis of an instruction or point; special terms.
	File names, path names, windows, panes, tabs, fields, variables, and other GUI elements.
	Titles of books and various documents.
<i>Blue italic</i>	(Electronic version.) Hyperlinks to cross-references, related topics, and URL addresses.
Monospace	Text that displays on the computer screen.
	Programming or coding sequences.

Safety terms and symbols

These terms may appear in this manual:



CAUTION: *Cautions* identify conditions or practices that may result in damage to the equipment or other property.



WARNING: *Warnings* identify conditions or practices that could result in equipment damage or serious personal injury.

1. Many GE documents are provided as PDFs (portable document format). To read these documents, you will need Adobe Reader, which can be downloaded free from Adobe's website at www.adobe.com.

Chapter 1 Introduction

This chapter describes the Simon XT's components.


In this chapter:

<i>Security system components</i>	2
<i>Communicating with your system</i>	4

Security system components

The Simon XT uses wireless technology to warn your family about intrusion and fire. It may also be used to control lights and appliances within your home. The system communicates with a central monitoring station and sends voice messages to an offsite phone.

Figure 1. Simon XT system



Note: The universal, lamp, and appliance modules require a special power supply board to be installed.

The security system uses sensors that communicate alarms to the control panel using radio waves.

The system is supervised, meaning that the panel checks the status of each sensor to detect problems. If the panel detects trouble, it will notify you with displayed and spoken messages, beeps, and indicator lights on the panel itself.

A Simon XT installation may include any of the devices listed in *Table 1* on page 3.

Table 1. Simon XT system components

Component	Type	Description
Control panel		Operates and programs your security system. It communicates to you through displayed and spoken messages. The panel can communicate to a central monitoring station and send voice messages to your off-site phone.
Sensors	Door/window	Detects the opening of a door or window.
	Indoor motion	Detects motion in a protected indoor area. When motion is detected, the panel may respond by sounding chimes or an alarm.
	Two-button pendant panic	A wireless device used for activating police and auxiliary alarms through your security system.
	Shock sensor	Detects vibration made by an intruder breaking a window or door.
	Smoke sensor	Detects smoke or a significant rise in temperature. They have a built-in siren that sounds when smoke or a significant rise in temperature is detected.
Touchpads	Keyfob	This keychain touchpad controls the security system from within or near the outside of your home.
	Two-way talking touchpad	Controls the security system from within your home and provides voice feedback.
Modules	Appliance	Can be programmed to turn appliances or fluorescent lights on and off.
	Lamp	Can be programmed to turn nonfluorescent lights on and off.
	Universal	Used for controlling devices other than appliances and lamps. Check with your installer for other applications.
	Ethernet	Provides broadband connection for communicating with the central monitoring station or the PremisesConnect server.
	GSM	Provides GSM network connection for communicating with the central monitoring station.

Communicating with your system

You can send commands or instruct your security system through a series of keypresses on the panel, touchpads, or a remote telephone.

Table 2. System communication devices

Device	Description
Control panel	You can enter commands for your security system through simple keypresses on the panel. Depending on how your system is programmed, you may need to enter an access code for certain commands. An access code is a numeric code that allows authorization to operate your security system.
Two-way talking touchpad	This touchpad controls the security system from within your home and provides voice feedback. You can enter commands through simple keypresses on the touchpad.
Keyfob	Keyfobs are handy for simple arming, disarming and light control functions. They are portable and can be carried offsite in a purse or pocket.
Telephone	You can use touchtone telephones to communicate with your system while you are offsite. Ask your installer if you have this feature.

Note: The default master code is 1-2-3-4 when the security system is shipped from the factory. If your installer has changed the length of the system codes, the default master code may also be 1-2-3, 1-2-3-4-5, or 1-2-3-4-5-6. You should change your code after your system is installed. See [Code options](#) on page 24.

Chapter 2 Using the control panel

This chapter provides instructions for operating your Simon XT Security System.

In this chapter:

<i>Panel controls</i>	6
<i>Simon XT features</i>	9
<i>Using an offsite phone</i>	15
<i>Using touchpads</i>	16

Panel controls

You can operate the self-contained security system through several different methods:

- The front panel buttons provide a means of arming and disarming the system when you enter or exit your home. These buttons also provide a method for determining which sensors are active and determining system status.
- A set of three fast action keys provide immediate communication with the central monitoring station to report police, fire, or auxiliary alarms.
- The more complex operating functions are achieved using a combination of the panel buttons and a display menu. This method is used by your installer to establish your system configuration. You can use this method to program certain user features. See [Menu navigation](#) on page 25.

The self-contained panel (*Figure 2*) provides the user interface for system operation and programming system functions. *Table 3* on page 7 provides a description of the panel keys and display.

Figure 2. Simon XT self-contained panel













Table 3. Simon XT panel keys and features

Control	Description
Piezo siren	The piezo siren makes alarm beeps and status beeps. Fire and intrusion alarm beeps are always played at high volume, while the volume of status beeps (such as trouble or chime beeps, entry and exit delay beeps, or auxiliary alarm beeps) is programmable.
LCD display	The LCD module has a 2 x 16 character array that displays a variety of phrases and icons.
Away 	Press to arm perimeter and interior sensors.
Stay 	Press to arm perimeter sensors.
Disarm 	Press to turn off intrusion/burglary protection for your system. Only intrusion/burglary sensors such as doors, windows, and motion sensors are disarmed. Environmental sensors, such as smoke and carbon monoxide, stay active at all times.
Status 	Press to determine system status.
Silent 	Press to silence exit beeps when arming.
Bypass 	Press to bypass a sensor.
Emergency 	Press and hold the Emergency button for two seconds (or press twice quickly) to call the central monitoring station and notify them of a nonmedical call for help.
Police 	Press and hold the Police button for two seconds (or press twice quickly) to call the central monitoring station and notify them of a nonmedical call for help.
Fire 	Press and hold the Fire button for two seconds (or press twice quickly) to call the central monitoring station and notify them of a nonmedical call for help.
Microphone	Used to communicate with central monitoring station after an alarm.
Scroll up/scroll down	Press to scroll through lists of similar items.
Enter	Press to select a particular menu item or commit to memory a menu item that has just been programmed.
Numeric keypad	Twelve-key telephone-type keypad (0 through 9, *, #) for entering access codes or other numerical data.
Speaker	Provides voice output and sounds key beeps. The panel speaks arming level changes, system status, and voice chime sensor trips. The panel voice is also used for voice reporting and remote phone control.
Door	Covers the lower panel.
*	Lights on.
#	Lights off.

Standard text display

While the panel is idle, the following text displays:

Display line 1	Arming level
Display line 2	HH:MMx (Time) and status icons

Note: Depending on how your system is configured, the arming level and status icons may only be displayed for 30 seconds following a keypress, after which the time appears on line 1 and line 2 is blank.

Arming level text could be one of the following:

- Subdisarm
- Disarm
- Stay
- Away

The phrase – *No delay* is appended to the arming level when no entry delay is active. Here are the possible status icons:

- 🔔 Chime - *Solid bell*
- 🔔 Special chime - *Outlined bell*
- 🕒 Light schedules - *Clock*
- 💡 Sensor lights - *Light bulb*
- 🔑 Latchkey on - *Key*

LEDs

Every key on the front keypad has an LED behind it, except for the scroll up and down keys. There are four status LEDs behind the row of keys below the LCD display. These status LEDs indicate the arming level. There is one status LED behind the **Enter** button. This status LED is lit when there are no open sensors in the system. All other LEDs are controlled as a group and provide backlighting for the keypad for 30 seconds after a key is pressed.

Simon XT features

Your Simon XT self-contained security system provides the following features:

- Home security
- Entry and exit delays
- Light control
- Emergency
- Bypassing sensors
- Chime
- Latchkey

Things you can do

The Simon XT features provide you with the ability to perform the following functions:

- Arm perimeter (stay) or entire system (away).
- Control lights to be turned on and off at a set time or if an intruder is detected.
- Use one button to send quick response alerts to the central monitoring station.
- Access the system from a keyfob that is similar to that used for your car.
- Access the system from a remote telephone.
- Disable sensors so you can leave a window open while the system is armed.
- Get an audio alert when a protected door is opened while the system is disarmed.
- Have the system notify you if your children do not arrive at home by a predetermined time.

Home security

The Simon XT allows you to control which sensors are active at any given time. *Table 4* describes the arming levels that you can set from the control panel.

Table 4. Simon XT arming levels

Level	Function	Description
0	Subdisarm	If your system includes 24-hour protection sensors on items such as gun or jewelry cases, you must subdisarm the panel before accessing these areas to avoid causing an alarm. Environmental sensors, such as smoke and carbon monoxide, stay active at all times.
1	Disarm	In this level, only 24-hour sensors are active.
2	Stay	This level arms the door and window sensors, while leaving the interior motion sensors disarmed.
3	Away	This level lets you arm the interior motion sensors and the exterior door and window sensors.

Arming/disarming

Arming a sensor makes it active and allows the panel to generate an alarm when a door or window is opened, or when an unauthorized person enters a specific area. Disarming makes the sensor inactive in the system. The current arming level is shown on the panel display and changes in arming level are announced on the speaker.

Subdisarm

1. Enter the master code while the system is disarmed.
2. The panel displays and speaks *Subdisarmed*, the **Disarm** button blinks, and the panel beeps once.
3. When you've finished accessing the temporarily unprotected areas, press **Disarm** to return to *Disarmed*.

Disarm (off)

1. Press **Disarm**, then enter your code when the panel displays *Enter code*.
2. The panel displays and speaks *Disarmed*, the **Disarm** button lights up, and the panel beeps once.

Arming doors and windows (Stay)

1. Ensure that all doors and windows are closed.
2. Press **Stay**, then enter your code when the panel displays *Enter code*, if a code is required.
3. The panel displays *Stay*, speaks *Stay*, and the **Stay** button lights up.
4. The panel starts an exit delay, and sounds exit beeps in groups of 2 until the exit delay expires.

Arming doors, windows, and motion sensors (Away)

1. Press **Away**, then enter your code when the panel displays *Enter code*, if a code is required.
2. The panel displays *Away*, speaks *Away*, and the **Away** button lights.
3. The panel starts an exit delay and sounds exit beeps in groups of four until the exit delay expires.

Exit/entry delay

Your Simon XT provides a delay after entering or exiting your home before the system is alarmed. *Table 5* provides details for the entry and exit delay features.

Table 5. Entry and exit delay details

Function	Description
Entry delay	Some active sensors cause immediate alarms when tripped. Other sensors, if enrolled in a delayed response group, start an entry delay that lets you enter the premises and disarm the system. If the system has not been disarmed by the end of the entry delay, the alarm occurs.
No delay	If the system was armed with the no delay feature activated, there will be no entry delay and the alarm will occur immediately.
Exit delay	When the user arms the system, an exit delay starts. During the delay the user can vacate the premises through a delayed response door without causing an alarm.
Protest during arming	The system may protest an arming level change if certain abnormal conditions exist. If a sensor that is active in the requested arming level is open, the system sounds protest beeps and automatically bypasses the open sensor (depending on system configuration).

Exit delay

The exit delay is the amount of time the system gives you to exit the home before the system is armed. This is programmed by the installer. After you arm the system you will hear beeps during the exit delay. See [Status beeps](#) on page 21.

Silent exit

The silent exit feature silences the status beeps that accompany the exit delay. See [Status beeps](#) on page 21. Press **Silent** after you arm the system to silence status beeps. The panel will still beep at the beginning and end of the exit delay.

Note: Enabling silent exit doubles the exit delay time.

Entry delay

The entry delay is the amount of time the system gives you to disarm the system after entering the home. This is programmed by the installer. When you enter your home, you will hear beeps during the entry delay. See [Status beeps](#) on page 21.

No entry delay

Use the no delay feature when you are staying at home, for instance when you are asleep, or when you're away from home and will carry a wireless touchpad that will allow you to disarm the system before opening a protected door. Check with your installer to find out how this option is programmed.

1. Close all doors and windows.
2. Press the **Stay** button twice. If a code is required for arming, enter your code after the first press of the **Stay** button, then press the button again.
3. The panel displays *Stay - no delay* and speaks *Stay, no entry delay*. The **Stay** light will blink and the exit delay will begin.

Note: To avoid causing an alarm, you must disarm the system with a wireless touchpad before entering your home.

Quick exit

Use the quick exit feature when someone wants to briefly leave while the home is still armed (for instance to get the newspaper). This feature needs to be enabled by your installer. When you press the **Disarm** button, the display shows *Exit time is on*. This allows a designated exit door to be open for up to two minutes without triggering an alarm.

Note: The designated door may be opened and closed only once. If you close the designated door behind you when you exit, you will have to disarm the system upon reentering. Leave the designated door open while using the quick exit feature.

Exit delay extension

If enabled by your installer, the exit delay extension feature will recognize when you arm the system, leave your house and then quickly re-enter your house (such as you would if you forgot your car keys.) In such a case Simon XT will restart your exit delay to give you the full exit delay again.

Bypassing sensors

Bypassing a sensor allows you to open the sensor while the system is armed. For example, if your system is armed and you want to open your kitchen window but do not want to disarm the entire system, you can bypass the kitchen window sensor and then open the kitchen window without causing an alarm. Bypassed sensors are automatically unbypassed when the arming level is changed to a level where the sensor is not active.

Bypassing

1. Press **Bypass** and enter the master code.
2. Scroll up/down until you reach the sensor to be bypassed.
3. The display shows, for example, *Sn 1 front door* on the first line.
4. Press **Enter** to bypass (deactivate) the sensor.
5. When a sensor is bypassed, the panel displays *Bypassed* on the second line.

Unbypassing

1. Press **Bypass** and enter the master code.
2. Scroll up/down to the sensor to be unbypassed. The sensor must be currently bypassed.
3. Press **Enter** to unbypass (reactivate) the sensor.
4. The panel removes the word *Bypassed* from the second line of the display.

Alarms

The system provides a series of alarms that indicate an unusual occurrence. When an alarm is active, the panel displays:

Alarm Alarm Alarm

Press Status

Alarms are canceled by entering a valid master or user code. After alarms are canceled, the system will be disarmed.

Canceling and preventing accidental alarms

One of the biggest concerns you might have regarding your security system is causing an accidental alarm. Most accidental alarms occur when leaving the residence after arming the system or before disarming the system upon your return.

There is a communicator delay (dialer delay) of 30 seconds programmed into this panel. Usually, the panel will delay 30 seconds before dialing the central monitoring station to send reports. You can have your installer program this delay time between 0 and 254 seconds. To cancel an accidental alarm before the programmed dialer delay time expires, enter your access code.

Guidelines for preventing accidental alarms

Use the following guidelines to prevent accidental alarms.

- Close doors and windows before you leave your house.
- Gather your belongings, so you can exit immediately after arming the system.
- Always enter and exit within the programmed delay times.
- Make sure you leave through a door that has a delay time set for it.
- Disarm your system immediately upon returning home.
- Be aware of the devices in your security system and learn how each one operates.
- If you have pets, ask your installer if you need pet lenses in your motion detectors.
- Check the location of your smoke detectors. Smoke detectors near bathrooms and kitchens can be tripped by steam and smoke from cooking.
- Make a note of the display, system beeps, and indicator lights that indicate the current system status.

Light control (optional)

Simon XT lets you control lights and appliances using lamp, appliance, or universal modules. You can do the following:

- Turn lights with unit numbers 1 to 8 on or off manually or at a specific time.
- Turn on lights when a sensor is tripped. You can program lockout times when sensor-activated lights won't be active.

To turn on all of the lights that are controlled by lamp modules, press the * button twice. The panel display will show *All lights on*. To turn off all lights that are controlled by lamp modules, press the # button twice. The panel display will show *All lights off*. To turn on or off individual lights, do the following:

- To turn on a light with unit number N (1 to 8), press the * button, then <N>. The panel displays and speaks *Light <N> On*.
- To turn off a light with unit number N (1 to 8), press the # button, then <N>. The panel displays and speaks *Light <N> Off*.

Chimes

Use the chime feature to signal when a protected door is opened while the system is disarmed. The panel chimes twice when a chime sensor is tripped, if the chime mode is enabled. This feature allows you to be notified when family members are going in and out of your home. The chime and special chime features are turned on or off in the system menu. See [Chime](#) on page 28 and [Special chime](#) on page 28.

Note: If there are no chime sensors in your system, the chime option will not be in the System menu.

Voice chime

Your installer may have programmed the system to speak the sensor name or make a custom chime sound when a chime sensor is tripped. The chime sound, if programmed, will be played in place of the standard chime beeps.

Special chime

Special chime allows you to install motion sensors in a patio or at the front door, and be notified when someone is approaching those areas. These motion sensors are not used for intrusion protection. The panel will chime three times, if the special chime mode is enabled.

Note: If there are no special chime sensors in your system, the special chime option will not be shown in the *System* menu.

Latchkey

Use the latchkey feature to notify you, via a remote phone, if a family member does not arrive home at a predetermined time and disarm the system. When this feature is active, a latchkey alarm is reported if the premises are not disarmed by the programmed latchkey time. For example, if you set the latchkey time for 3:00 p.m. and the system is not disarmed by that time a message is sent to your remote phone. The latchkey feature can be activated during arming if a latchkey time is programmed.

To activate the latchkey feature, do the following:

1. Press **Away** twice. If a code is required, enter your code after the first press of the **Away** button, then press **Away** a second time.
2. The panel speaks *Away latchkey* and displays the latchkey icon, and the exit delay will begin.

System status

Press **Status** (a code may be required) to cause the system to display and speak the following types of information:

- Alarm conditions
- Alarm history
- Trouble conditions
- Open sensors
- Bypassed sensors

The **Status** button blinks when an active alarm exists. The **Status** button is lit when an abnormal condition such as a trouble or open sensor exists in the system.

You can clear certain status entries from the system (such as old alarm history) by pressing **Disarm** after checking the status.

Note: Like the bars on your GSM phone, the panel will indicate the signal level of its GSM module based on the number of boxes filled in. The more boxes filled, the greater the signal strength. Three or more bars indicates a good signal level, while one bar or less indicates a weak signal.

Using an offsite phone

If enabled by the installer, you can control your Simon XT panel remotely from an offsite phone. The panel answers a phone call according to the dialing method programmed by your installer.

After a certain combination of rings and pauses, the panel will answer the call with the voice prompt *Enter your code*. You must enter the correct code to gain access.

If you are interacting with your panel and the panel hangs up on you, the system is calling in a report to the central monitoring station or remote phone due to an action by you or someone at the security system site. The actions listed in *Table 6* may be performed from an offsite phone.

Table 6. Phone controls

Action	Phone keypresses	Comments
Disarm	❶	System not already disarmed
Subdisarm	❶	Must have used the master code to gain access; system was disarmed
Arm doors and windows (Stay)	❷	Press 2 again to activate <i>No delay</i> feature
Arm doors, windows, and motion sensors (Away)	❸	Press 3 again to activate <i>Latchkey</i> feature
Check status	❶	
Turn light on	*-<unit_num>.	N = 1-8, unit number
Turn light off	#-<unit_num>.	N = 1-8, unit number
Turn all lights on	* _ *	
Turn all lights off	# - #	
Hang up	❾	
2-way voice session	❺	During session, pressing 1 turns speaker on, 3 turns microphone on, 9 ends session (hangs up). If no keypresses are heard by the panel for 90 seconds, it will hang up. After each keypress, the panel will send a short tone.


Using touchpads

You can use touchpads to control the security system from any location within or near your home.

Two-way talking touchpad


Interfacing with the system using a two-way talking touchpad is similar to using the panel.

Figure 3. Two-way talking touchpad




Keyfob

If your installer programmed the keyfob with no entry delay, and you armed the system with the keyfob, you must disarm your system before entering the home to avoid causing an alarm.



CAUTION: To avoid causing false alarms, check with your installer on how your touchpad options are programmed.












Figure 4. Keyfob (keychain touchpad)



Note: For any keypress on the keyfob, hold the button until the indicator light blinks

If your installer programmed your system for remote touchpad arming, you must enter your home to start the entry delay before you can use your keyfob to disarm the system.

Note: Panic alarms need to be silenced from the panel, a remote handheld touchpad, or another keyfob. They cannot be silenced from the same keyfob that activated the alarm.

	Lock	Press once for <i>Stay</i> .
 - 	Lock	Press twice for <i>Away</i> .
 -  - 	Lock	Press three times for <i>Away</i> , and to activate the latchkey option.
 +  Hold both for 3 sec.	Lock and unlock	Press both buttons simultaneously for three seconds to send a panic (intrusion, silent, or nonmedical emergency) alarm to the central monitoring station. Check with the installer to find out how the keyfob panic buttons will operate.
	Unlock	Press to disarm your security system.
	Star	Can be programmed to control a device connected to a universal module.
	Light	Can be programmed to control a device connected to a lamp module. Press once to turn on all lights on lamp module. Press again to turn off all lights on lamp module.

Chapter 3 How your system communicates

Your system responds to you through the use of display and voice messages, status beeps, alarms, and panel indicator lights.

In this chapter:

<i>Alarm sirens and lamp modules</i>	20
<i>Panel indicator lights</i>	20
<i>Status beeps</i>	21
<i>Trouble beeps</i>	21

Alarm sirens and lamp modules

Exterior and interior sirens make three different alarm sounds on the premises, each indicating a different type of alarm. Sirens are programmed by the installer to time out and stop sounding after a specified time.

Use *Table 7* to understand the siren sounds used by the security system.

Table 7. Alarm Siren and X10 Light Information







Function	Fire	Intrusion	Emergency
X10 Lights	Steady	Flashing	Steady
X10 Siren	Steady	Steady	Alarm beeps
Interior and panel siren	Temporal 3 ^a	Steady	Fast on/off
Exterior siren	Temporal 3 ^a	Steady	

a. Temporal 3 refers to a continuous pattern of three siren pulses, then off for 1.5 seconds, three siren pulses, then off for 1.5 seconds.

Panel indicator lights

Use *Table 8* to understand the panel indicator lights.

Table 8. Panel indicator lights

Button or display icon	When button light or display icon is on	When the button flashes
Stay	Doors and windows armed	Doors and windows armed and no entry delay on
Away	Doors, windows, and motion sensors armed	Doors, windows, and motion sensors armed, and latchkey on
Disarm	System disarmed	System subdisarmed
Status	System trouble, open sensor, or bypassed sensor	System in alarm
Enter	There are no open sensors	
 Chime - Solid bell	Door will cause chime	
 Special chime - Outlined bell	Motion will cause chime	
 Light schedules - Clock	Time-activated lights feature enabled	
 Sensor lights - Light bulb	Sensor-activated lights feature enabled	
 Latchkey on - Key	Latchkey feature enabled	
 GSM (mobile) signal bars	Three or more solid bars = signal good Less than two solid bars = signal low	

Status beeps

The panel sounds status beeps to alert you to various system events and conditions.

Note: You may receive a different number of status beeps if you press the buttons quickly.

Table 9. Status beeps

Activity	Beep Response
Stay	Exit delay and Entry delay beeps sound two times every five seconds and two times per second during the last ten seconds. If silent exit is used, the exit delay beeps will only sound twice when you arm and twice when the exit delay expires.
Away	Exit delay and Entry delay beeps sound four times every five seconds and four times per second during the last ten seconds. If silent exit is used, the exit delay beeps will only sound four times when you arm and four times when the exit delay expires.
Disarm	One beep.
Chime	Two beeps.
Special chime	Three beeps.
Trouble beeps	Six beeps every minute. Press Status to stop beeps for four hours. The time interval can be increased by the installer to up to 12 hours.
No activity beeps	Twenty beeps every minute for five minutes. Feature must be programmed by the installer.

Trouble beeps

Your security system is able to automatically test itself for:

- Power failures
- Low batteries
- Nonworking sensors
- Communication troubles with the central monitoring station

When your security system detects one of the problems above, six rapid beeps sound every minute until the trouble condition is corrected. To stop the trouble beeps, press **Status** or arm/disarm the system while the trouble condition exists. Trouble beeps will resume four hours later (up to 12 hours if programmed by the installer) unless the trouble condition is corrected.

The following list explains the trouble beep conditions:

AC power failure. This condition (if programmed by installer) occurs if your security system has been accidentally unplugged or if there has been an AC power outage. Any status lights go out immediately, and trouble beeps start after five minutes. If you press any button, the display will light and pressing **Status** will show the AC failure. If AC power is not restored within a programmed period of time (5 to 254 minutes) the system will call the central monitoring station. The backup battery, if fully charged, will last for at least 12 hours — depending on the load applied to the panel — with no AC power.

System battery failure. This condition occurs if the emergency backup battery has failed. Trouble beeps will start. Press the **Status** button and the display will show *System low battery*. If your AC power is not working, your security system will shut down once the battery has failed. If the condition does not clear after AC power has been restored and 24 hours have passed, call your security system dealer.

Restoration of power. This condition occurs after a complete loss of power (AC and battery). When power is restored, the panel will return to the arming state with the same zones bypassed it had prior to losing power.

Sensor failure. This condition occurs if a sensor is not communicating with the panel. Trouble beeps will start and the **Status** button will light. Press the **Status** button and the display will show what sensors have failed. Perform sensor tests. You may need to call your security system dealer if the problem continues.

Sensor low battery. This condition occurs if a system sensor has a low battery. The sensor may still be communicating with the panel. Trouble beeps will start and the **Status** button will light. Press the **Status** button and the display will show what sensors have a low battery. You may need to call your security system dealer to resolve this problem. Some sensor batteries can be replaced by the homeowner.

Fail-to-communicate. This condition occurs if your security system cannot communicate to the central monitoring station. Your system will try to report to the central monitoring station eight times before it tells you there is a fail-to-communicate problem. Trouble beeps will start and the **Status** button will light. Press the **Status** button and the display will show *Comm test fail* or *Comm fail*. You may need to call your security system dealer if the problem continues.

Sensor open. This condition occurs if a door or window is open or a system sensor has been disturbed and not reset properly. For example, a door/window sensor magnet may have been removed from the sensor. Your system will indicate this condition to you by causing the **Status** button to light. When you press the **Status** button, the display shows, for example, *Sn 1 front door open*. Correct the problem by resetting the sensor. If this condition continues, call your security system dealer.

Sensor tampered. This condition occurs when a sensor is physically tampered with, for example, the cover is taken off of one of the sensors. If the system is armed an alarm will occur. Your system will indicate this condition to you by causing the **Status** button to light. Trouble beeps will start. Press the **Status** button and the display shows *Sn # name tampered*. Correct the problem by resetting the sensor. If this condition continues, call your security system dealer.

RF jam detected. The panel receiver may be experiencing some interference. The system will call to notify the central monitoring station about this problem.

Clearing status. Some types of status conditions, such as the alarm history, must be cleared manually. To clear system status, press the **Status** button, read and/or listen to the status messages, then press **Disarm**. If the trouble condition was a low system battery, perform a sensor test. The **Status** light should turn off if all trouble conditions have been corrected.

Chapter 4 Programming

This chapter describes how to program your system. It will guide you through programming instructions for system features.

- System menu*24
- Menu navigation*25
- Top-level menus*27
- System programming*30

System menu

Your Simon XT self-contained security system security system allows you to program certain user options, such as access codes, time schedules, or the system time. These options are accessed through a system menu.

Entering and exiting the system menu

To enter the system menu, press the scroll up/down buttons or the **Enter** button in the upper right of the panel.

Press **Status** to exit a menu or option edit mode and navigate up one level. Pressing **Status** while in the top menu level exits the system menu. The panel automatically exits the system menu after a few seconds of inactivity if no access code has been entered. After an access code has been entered to access a code-protected area of the system menu, the timeout is 30 minutes.

Code options

The Simon XT security system provides a system of codes to be entered when a certain level of authority is required to perform an action. These codes allow you to activate system options, customize panel operations, and generate a silent alarm. The default code is based on the code length (3, 4, 5, or 6-digit code) determined at installation. The code types are listed in *Table 10*.

Table 10. Simon XT system codes

Code	Description
Master code	The master code is the main code used for panel operations. The default code will be 123, 1234, 12345, or 123456 depending on the value set by the installer for code length.
User codes 1 through 8	These eight codes are supplemental user codes. These codes can be used for panel operations such as disarming, but not programming. These codes can be any 3, 4, 5, or 6-digit code, depending on the code length.
Duress code	The duress code is used to generate a silent duress alarm while disarming.

Note: Any combination of invalid codes in excess of 40 keypresses (such as fourteen invalid three-digit codes) will cause a system access alarm. The alarm locks all touchpads, except keyfobs, for 90 seconds.

Menu navigation

Each menu contains a list of options and/or submenus. Press the scroll up/down buttons to navigate up and down the list of options and submenus in that menu. Pressing **Enter** after navigating to an option selects that option for editing and flashes the current value. Pressing **Enter** after navigating to a submenu enters that submenu, making a new list of options accessible. Pressing **Status** exits and goes to the next higher level.

Programming options are arranged in a menu structure as outlined in *Table 11*. The top menu contains several features, as well as the *System programming* menu. When accessing the *System programming* or *System tests* menu, the panel prompts you to enter an access code. To continue, enter the master code, then press **Enter**.

To program an option, first navigate to that option until it is displayed, then press **Enter**. The option value will start flashing, indicating that it is ready to be changed. Use the scroll keys or enter a numerical value to change the option, then press the **Enter** key to save the change.

Table 11. Simon XT menu structure

Set clock (page 27)
Set date (page 28)
Light schedules (page 28)
Sensor lights (page 28)
Chime (page 28)
Special chime (page 28)
View event buffer (page 29)
System tests (page 29)
Sensor test
Communication test
Initiate call to downloader
Initiate call to flashloader
System programming (page 30)
Access codes (page 30)
Master code
User code 1
User code 2
User code 3
User code 4
User code 5
User code 6
User code 7
User code 8
Duress code
Security (page 31)
Downloader code
Master code enabled programming
Phone numbers (page 32)
Phone #1
Phone #2
Phone #3
Phone #4
Timers (page 32)
Latchkey time
System options (page 33)
Date format
Date order
Separator
Year format
Month format
Day of week
Daylight saving time (DST)
DST start date
DST start time and offset
DST end date
DST end time and offset
Siren options (page 34)
Panel piezo beeps
Panel voice
Panel piezo alarms
Voice chime
Status beep volume
Speaker volume
Light control (page 36)

Set entry lights
Sensor lights
Light schedules
Housecode
Sensor-activated light lockout time
Ethernet configuration (page 37)
General
Current panel IP address
Current router IP address
Current subnet mask
MAC address

GSM configuration (page 37)
Manufacturer
Model
Software revision
Serial number
Current operator
RSSI (signal strength)
BER (error rate)
GSM network status
PUK required
System tests (page 29)
Sensor test
Communication test
Initiate call to downloader
Initiate call to flashloader
Revision (page 29)
Contrast (page 29)

Top-level menus

This section explains the top-level menus, with the exception of system programming, which makes up the bulk of the menus and can be found in its own section, [System programming](#) on page 30.

Set clock

If the panel loses both AC and battery power, the system time will reset to midnight and blink when power is restored, indicating that the time is not correct. Your installer has set the system time to display in 12- or 24-hour format.

Time of day format is HH:MMx, where:

HH = 01 to 12 (12-hour format) or 00 to 23 (24-hour format)

MM = 00 to 59

x = *a* or *p* (12-hour format) or blank (24-hour format)

To set the clock, do the following:

1. Scroll up/down until the display shows *Set clock*.
2. Press **Enter**. The display shows *Enter code*.
3. Enter your code with the numeric keys and press **Enter**. The display shows *Set clock*.
4. Press **Enter**. The display flashes the hours.
5. Scroll up/down to set the hours.
6. Press **Enter**. The display flashes the minutes.
7. Scroll up/down to set the minutes. If using 24-hour format, skip to step 10.
8. Press **Enter**. The display flashes *AM/PM*.
9. Scroll up/down to select a.m. or p.m.
10. Press **Enter**. The display shows the current time and stops flashing.
11. Press **Status** twice to exit.

Set date

The date displays in the format YYYY-MM-DD. To set the date, do the following:

1. Scroll up/down until the display shows *Set date*.
2. Press **Enter**.
3. Scroll up/down to set the year or enter the year using the numeric keypad.
4. Press **Enter**.
5. Scroll up/down to set the month or enter the month number using the numeric keypad.
6. Press **Enter**.
7. Scroll up/down to set the day or enter the day (with a leading zero if necessary) using the numeric keypad. Invalid days such as February 30 will not be accepted.
8. Press **Enter**. The display shows the current date and stops flashing.
9. Press **Status** twice to exit.

Light schedules

This option lets you enable/disable time-scheduled lights. It only appears in the menus if time schedules are programmed. Press **Enter** to edit, scroll to select *On* or *Off*, then press **Enter** again to save. Press **Status** to exit.

Sensor lights

This option lets you enable/disable sensor-activated lights. It only appears in the menus if you have sensors associated with lights. Press **Enter** to edit, scroll to select *On* or *Off*, then press **Enter** again to save. Press **Status** to exit.

Chime

This option lets you enable/disable the chime feature. It only appears in the menus if you have chime sensors. Press **Enter** to edit, scroll to select *On* or *Off*, then press **Enter** again to save. Press **Status** to exit.

Special chime

This option lets you enable/disable the special chime feature. It only appears in the menus if you have special chime sensors. Press **Enter** to edit, scroll to select *On* or *Off*, then press **Enter** again to save. Press **Status** to exit.

View event buffer

This menu item is a read-only display of the last 250 events in the system's flash buffer. The display shows the event number, starting at 000, and the event description on the first line. The display shows the time and date of the event on the second line.

Use the following keys to view information not on the display:

- **Silent** scrolls to the left.
- **Bypass** scrolls to the right.
- **Silent + Bypass** together switches the line you are scrolling.

Scroll up to display events from latest (#000) to earliest. Press **Status** to exit.

System tests

This menu lets you run sensor and communication tests, and initiate a phone call from the panel to the Enterprise Downloader. For more information, see *Chapter 5 Testing* on page 39.

Revision

This menu item is a read-only display of the system's firmware version.

Contrast

To adjust the contrast of the display, do the following:

1. Scroll up/down to *Contrast*.
2. Press **Enter**.
3. Scroll up/down to increase and decrease the contrast setting. (There are eleven contrast levels.)
4. Press **Status** to save the setting and exit.

Note: Changes in contrast are more noticeable when not looking at the display straight on.

System programming

To enter system programming mode, do the following:

1. Press the scroll buttons until the panel displays *System programming*.
2. Press **Enter**. The system prompts for an access code.
3. Enter your master code. The system displays each entered access code digit as an asterisk.
4. Press **Enter**. The panel is now in program mode.

At this point, you are in the *System programming* submenu. At this level, the following items are accessible:

- [Access codes](#)
- [Security](#) on page 31
- [Phone numbers](#) on page 32
- [Timers](#) on page 32
- [System options](#) on page 33
- [Siren options](#) on page 34
- [Light control](#) on page 36
- [Ethernet configuration](#) on page 37
- [GSM configuration](#) on page 37
- System tests

The following sections describe the options that you can program in the *System programming* menu.

Access codes

There are three types of access codes: master, user, and duress.

Master code. The master code is your most powerful code and can be used for all user operations including programming. To change the master code, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Access codes*, then press **Enter**.
3. Scroll up/down to *Master code*, then press **Enter**.
4. A flashing cursor is now displayed.
5. Enter a new code (use correct length), then press **Enter**.
6. Press **Status** repeatedly to exit.

The initial value of the master code is 123, 1234, 12345, or 123456, depending on the installer-programmed access code length.

User codes 1 to 8. There are eight user codes, which can be used for many user operations, but not subdisarming, programming, or bypassing sensors.

To change a user code, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Access codes*, then press **Enter**.

3. Scroll up/down to the user code you want to change, then press **Enter**.
4. A flashing cursor is now displayed.
5. Enter a new code (use correct length), then press **Enter**.
6. Press **Status** repeatedly to exit.

Initially, all user codes are blank. You can delete a user code by pressing **Disarm** while changing the code.

Duress code. The duress code, when used in place of another user code, generates a silent duress alarm which is reported to the central monitoring station.

To change the duress code:

1. Enter the *System programming* menu.
2. Scroll up/down to *Access codes*, then press **Enter**.
3. Scroll up/down to *Duress code*, then press **Enter**.
4. A flashing cursor is now displayed.
5. Enter a new code (use correct length), then press **Enter**.
6. Press **Status** repeatedly to exit.

Initially, the duress code is blank. You can delete the duress code by pressing **Disarm** while changing the code.

Security

The *Security* menu contains the *download enable* and *master code enabled programming* options.

Download enable. This option determines whether your dealer can access the system remotely.

To program the download enable option, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Security*, then press **Enter**.
3. Scroll up/down to *Download enable*, then press **Enter**.
4. The current value of this option now flashes.
5. Scroll up/down to toggle this option on/off, then press **Enter**.
6. Press **Status** repeatedly to exit.

Master code enabled programming. This option requires the master code to authorize any dealer or installer programming when turned on.

To change the master code enabled programming, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Security*, then press **Enter**.
3. Scroll up/down to *Master code enabled programming*, then press **Enter**. The current value of this option flashes.

4. Scroll up/down to toggle this option on/off, then press **Enter**.
5. Press **Status** repeatedly to exit.

Phone numbers

You can change phone numbers 1 to 4 if they have been set up for voice reporting of alarms by the installer.

To change phone numbers 1 to 4, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Phone #s*, then press **Enter**.
3. Scroll up/down to *Phone #1* to *Phone #4*, then press **Enter**.
4. The current phone type value flashes: GSM (mobile) or PSTN (land line). Scroll up/down to select the phone type you want, then press **Enter**.
5. The first digit of the current value of the phone number now flashes (this phone number may take up both lines on the display).
6. Change each digit of the phone number by scrolling or entering a numerical value, then move to the next digit by pressing **Enter**.
7. When done, press **Enter** again to save the new phone number.
8. Press **Status** repeatedly to exit.

The phone number can be deleted by pressing the **Disarm** button while changing a digit.

Timers

The latchkey time option is the only timer setting available to you. The latchkey time is the time of day by which the panel must be disarmed to avoid triggering a latchkey alarm, if the latchkey time option is enabled during arming.

To change the latchkey time, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Timers*, then press **Enter**.
3. Scroll up/down to *Latchkey time*, then press **Enter**.
4. The *HH* (hours) part of the time now flashes.
5. Program the hour value by scrolling or entering a numerical value, then press **Enter**.
6. The *MM* (minutes) part of the time now flashes.
7. Program the minute value by scrolling or entering a numerical value, then press **Enter**.
8. If you are using 12-hour clock format, the *a* or *p* (AM/PM) part of the time now flashes.
9. Select *a* or *p* by scrolling, then press **Enter**.
10. Press **Status** repeatedly to exit.

System options

You can change the date format and the daylight saving time options.

Date format. You can change the day/month/year order, separator, year format, and month format of the dates that are displayed in the event buffer. To program the date format, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *System options*, then press **Enter**.
3. Scroll up/down to *Set date format* (the current date and time are displayed in the programmed format), then press **Enter**.
4. Do the following, depending on which item you want to change.
 - To program the date order, scroll up/down to *Set date order*, press **Enter** and scroll to select the desired value, then press **Enter** again to save. The available values are *Day Month Year*, *Month Day Year*, and *Year Month Day*.
 - To program the separator, scroll up/down to *Set separator*, press **Enter** and scroll to select the desired value, then press **Enter** again to save. The available values are - (hyphen), . (period), and / (slash).
 - To program the year format, scroll up/down to *Set year format*, press **Enter** and scroll to select the desired value, then press **Enter** again to save. The available values are *None*, *2-digit*, and *4-digit*.
 - To program the month format, scroll up/down to *Set month format*, press **Enter** and scroll to select the desired value, then press **Enter** again to save. The available values are *2-digit number* and *Abbreviated name*.
5. Press **Status** to go back to *Set date format*. Press **Status** repeatedly to exit.

Daylight saving time. You can change the dates and times that daylight saving time (DST) starts and ends, as well as the magnitude of the adjustment. To program the DST, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *System options*, then press **Enter**.
3. Scroll up/down to *Set daylight saving*, then press **Enter**.
4. Do the following, depending on which item you want to change.
 - To program the DST start date, scroll up/down to *DST start date* and press **Enter** repeatedly to advance to one of the three items you can change — the week number, the day of the week, and the month of the start date. Scroll to select the desired value, then press **Enter** to save.
 - To program the DST start time and offset, scroll up/down to *DST start time* and press **Enter** repeatedly to advance to one of the four items you can change — the start time hours and minutes and the offset hours and minutes. Scroll to select the desired value, then press **Enter** to save.
 - To program the DST end date, scroll up/down to *DST end date* and press **Enter** repeatedly to advance to one of the three items you can change — the week number, the day of the week, and the month of the end date. Scroll to select the desired value and then press **Enter** to save.
 - To program the DST end time and offset, scroll up/down to *DST End time* and press **Enter** repeatedly to advance to one of the four items you can change — the end time hour and minutes and the offset hours and minutes. Scroll to select the desired value and then press **Enter** to save.
5. Press **Status** to go back to *Set daylight saving*. Press **Status** repeatedly to exit.

Siren options

The panel has two built-in sound sources: a piezo siren and a speaker. The piezo siren makes alarm beeps and status beeps. Fire and intrusion alarm beeps are always played at high volume, while the volume of status beeps (such as trouble or chime beeps, entry and exit delay beeps, or auxiliary alarm beeps) is programmable. The speaker emits the panel's voice and also sounds beeps when a key is pressed. Its volume is also programmable.

The siren and built-in speaker options consist of the following:

Panel piezo beeps. Panel piezo beeps (status beeps sounded on the siren). This option determines whether or not the panel sounds nonalarm beeps.

To program piezo beeps, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Siren options*, then press **Enter**.
3. Scroll up/down to *Piezo beeps*, then press **Enter**.
4. The current value of this option now flashes.
5. Scroll up/down to toggle this option on/off, then press **Enter**.
6. Press **Status** repeatedly to exit.

Panel voice. Panel voice (spoken phrases on the speaker) and keypress sounds from the speaker heard while controlling the system. This option determines whether or not the panel speaks status messages and arming level changes.

To program panel voice, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Siren options*, then press **Enter**.
3. Scroll up/down to *Panel voice*, then press **Enter**.
4. The current value of this option now flashes.
5. Scroll up/down to toggle this option on/off, then press **Enter**.
6. Press **Status** repeatedly to exit.

Panel piezo alarms. Loud alarms on the siren. This option determines whether or not the panel sounds alarm beeps.

To program panel piezo alarm, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Siren options*, then press **Enter**.
3. Scroll up/down to *Panel piezo alarm*, then press **Enter**.
4. The current value of this option now flashes.
5. Scroll up/down to toggle this option on/off, then press **Enter**.
6. Press **Status** repeatedly to exit.

Voice chime. This option determines what sound the panel makes when a chime sensor is tripped. The choices are Off (no sound), 1 (sensor name), 2 (chime bell) or 3 (soft chime bell).

To program voice chime, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Siren options*, then press **Enter**.
3. Scroll up/down to *Voice chime*, then press **Enter**.
4. The current value of this option now flashes (off, 1, 2, or 3).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **Status** repeatedly to exit.

Status beep volume. This option sets the sound volume of nonalarm beeps. The numerical range is 1 to 10. The default value is 7.

To program status beep volume, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Siren options*, then press **Enter**.
3. Scroll up/down to *Status beep vol*, then press **Enter**.
4. The current value of this option now flashes (1 to 10).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **Status** repeatedly to exit.

Speaker volume. This option sets the sound volume of the panel speaker for keypresses and alarm sounds. The numerical range is 1 to 8. The default value is 8.

To program speaker volume, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Siren options*, then press **Enter**.
3. Scroll up/down to *Speaker volume*, then press **Enter**.
4. The current value of this option now flashes (1 to 8).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **Status** repeatedly to exit.

Light control

You can control certain lights by using X10 lamp, appliance, or universal modules. As set up by the installer, these modules have unit numbers from 1 to 8 and are set to the same housecode. These lights can be turned on for certain arming operations, when a sensor is tripped, or based on a time schedule. Light control includes:

Set entry lights. In this menu, each unit number can be set up as an entry light. These lights flash when the system is armed. An entry light flashes once when disarming, twice when arming to Stay, and four times when arming to Away.

To set entry lights, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Light control*, then press **Enter**.
3. Scroll up/down to *Set entry lights*, then press **Enter**.
4. Scroll up/down to the unit number you want to set, then press **Enter**.
5. The current option value flashes.
6. Scroll up/down to toggle this option on/off, then press **Enter**.
7. Press **Status** repeatedly to exit.

Sensor lights. In this menu, each sensor can be tied to a unit number. For example, a light in a room can be set up to turn on when a motion sensor in that room is tripped.

To set up sensor lights, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Light control*, then press **Enter**.
3. Scroll up/down to *Sensor light*, then press **Enter**.
4. The number and name of the first sensor are displayed, along with its associated unit number.
5. Scroll up/down to the sensor you want to set up, then press **Enter**.
6. The current option value now flashes (1 to 8 or Off).
7. Scroll up/down to the desired value or enter a numerical value, then press **Enter**.
8. Press **Status** repeatedly to exit.

Light schedules. In this menu, a light schedule can be programmed for each unit number (1 to 8).

To program light schedules, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Light control*, then press **Enter**.
3. Scroll up/down to *Light schedules*, then press **Enter**.
4. Scroll up/down to the desired light schedule (as defined by the unit number), then press **Enter**.
5. The current option value now flashes.
6. Enter the desired start time by entering the hours, minutes, and AM/PM (press **Enter** after programming each part).

7. Enter the desired end time by entering the hours, minutes, and AM/PM (press **Enter** after programming each part).
8. Press **Status** repeatedly to exit.

Housecode. To change the housecode, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Light control*, then press **Enter**.
3. Scroll up/down to *Housecode*, then press **Enter**.
4. The current option value (A to O) now flashes.
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **Status** repeatedly to exit.

Sensor-activated light lockout time. Each light (unit numbers 1 to 8) that has been tied to a sensor can be programmed not to turn on during a certain time of day.

To program the lock interval, do the following:

1. Enter the *System programming* menu.
2. Scroll up/down to *Light control*, then press **Enter**.
3. Scroll up/down to *Lock interval*, then press **Enter**.
4. Scroll up/down to the unit number for which you want to program a lockout time, then press **Enter**.
5. The current option value now flashes.
6. Program the start and end times (see [Light schedules](#) on page 36).
7. Press **Status** repeatedly to exit.

Ethernet configuration

The current panel IP address, current router IP address, current subnet mask, and MAC address are read-only network parameters that provide you with information about the configuration of the panel on your local Ethernet network. To read these parameters, enter the *System programming* menu, select the *Ethernet configuration* submenu, and then scroll to the appropriate option.

GSM configuration

The manufacturer, model, software revision, and serial number of the GSM modem, as well as the current GSM network operator, signal strength (RSSI), error rate (BER), GSM network status, and PUK status are read-only GSM parameters that provide you with information about the optional GSM module in the panel. To read these parameters, enter the *System programming* menu, select the *GSM configuration* submenu, then scroll to the appropriate option.

The GSM signal strength is also indicated in system status by the number of solid bars (filled rectangles) shown. Three or more bars (an RSSI level of 16 to 31) indicate a very good or excellent signal, and one bar or less (an RSSI level of less than 10 or equal to 99) indicates a weak signal.

Chapter 5 Testing

This chapter provides a set of tests to ensure proper operation of your Simon XT self-contained security system. We recommend you test your system weekly.

<i>Testing sensors</i>	40
<i>Testing communication</i>	41

Testing sensors

You can test sensors one at a time to make sure they are sending strong signals to the panel. You should test the security system at least once a week.

To perform the sensor test, do the following:

1. Scroll to *System tests*.
2. Press **Enter**. The display shows *Enter code*.
3. Enter your master code with the numbered keys.
4. Press **Enter** to accept the master code. The display shows *Sensor test*.
5. Press **Enter**. The display shows, for example, *Trip Sn 1 front door* and automatically displays the list of sensors to be tested. The panel sounds six beeps once a minute while in sensor test mode. See *Table 12*.

When you trip a sensor the display shows, for example, *Sn 1 packets = 8 front door*. You may trip the sensors in any order. As each sensor is heard from, it is removed from the list of sensors to be tested.

After all sensors have been successfully tested, the display shows *Sn test complete, press Status*. To terminate the sensor test, do the following:

1. Press **Status**. The display shows *Sensor test OK*.
2. After a few seconds the display shows *Sensor test*.
3. Press **Status** repeatedly to exit.

If any of the sensors did not test successfully and you want to terminate the test, press **Status**. The panel display will show *Sensor test fail or aborted*. The display then shows *Sensor test*. Press **Status** once to exit the system test. If a sensor test fails, call your security dealer.

Table 12. How to trip devices for sensor test

Device	To trip device
Door/window sensor	Open the secured door or window.
Motion sensor	Avoid the motion sensor's view for five minutes, then enter its view.
Shock sensor	Tap the glass twice, away from the sensor. Wait at least 30 seconds before testing again.
Smoke sensor	Press and hold the test button until the system sounds transmission beeps.
Two-button pendant panic sensor	Press and hold both buttons simultaneously for three seconds.
Keyfob	Press and hold lock and unlock simultaneously for three seconds.
Remote handheld touchpad	Press and hold the two emergency buttons simultaneously for three seconds.

Testing communication

Test communication between your system and the central monitoring station or a voice report destination at least once per week to make sure you have the proper telephone or internet connection.

To perform a communication test, do the following:

1. Scroll to *System tests*.
2. Press **Enter**. The display shows *Enter code*.
3. Enter the master code.
4. Press **Enter** to accept the master code. The display shows *Comm test*.
5. Scroll to *Comm Test*.
6. Press **Enter**. The display shows *Comm test is on*.
7. After the communication test is successful, the display shows *Comm test OK*.
8. Press **Status** repeatedly to exit.

Note: If your system is not connected to a central monitoring station and you do not have a voice report destination programmed, you won't be able to perform the communication test.

If the communication test is successful, the system displays *Comm test OK*. If the test is unsuccessful, the **Status** button will light and within ten minutes the panel will display *Comm fail* and a channel number that indicates which communication channel has failed. Channels 1 to 4 are the phone channels and channels 5 to 7 are the three Internet channels. If a communication test fails, call your security system dealer.

Appendix A Reference information

This appendix provides a list of system limitations, emergency planning, floorplan, and a quick reference command table.

In this appendix:

<i>Alarm system limitations</i>	44
<i>Emergency planning</i>	45
<i>Smoke and heat detector locations</i>	46
<i>Your floorplan</i>	47
<i>Battery removal/disposal instructions</i>	50
<i>Simon XT system quick reference</i>	51

Alarm system limitations

Not even the most advanced alarm system can guarantee protection against burglary, fire, or environmental problems. All alarm systems are subject to possible compromise or failure-to-warn for a variety of reasons.

- If sirens are not placed within hearing range of persons sleeping, in remote parts of the premises, or if they are placed behind doors or other obstacles.
- If intruders gain access through unprotected points of entry or areas where sensors have been bypassed.
- If intruders have the technical means of bypassing, jamming, or disconnecting all or part of the system.
- If power to sensors is inadequate or disconnected.
- If freeze or any environmental sensors are not located in areas where the appropriate condition can be detected.
- If smoke does not reach a smoke sensor. For example, smoke sensors cannot detect smoke in chimneys, walls, roofs, or areas blocked by a closed door. Sensors may not detect smoke in other levels of the building. Sensors may not warn in time when fires are caused by smoking in bed, explosions, improper storage of flammables, overloaded electrical circuits, or other hazardous conditions.
- If telephone lines are out of service.

Inadequate maintenance is the most common cause of alarm failure. Therefore, test your system at least once per week to be sure sensors, sirens, and phone communication are all working correctly.

Although having an alarm system may make you eligible for reduced insurance premiums, the system is no substitute for insurance.



WARNING: Security system devices cannot compensate you for the loss of life or property.

Emergency planning

Since an emergency is always unexpected, you should develop plans to help prepare for a variety of emergency situations. Periodically discuss and rehearse emergency plans to include the following:

- Understand how to use your security system.
- Know the normal state of doors and windows: open, closed, or locked.
- Escape fast! (Do not stop to pack.)
- Use a different escape route if closed doors feel hot to the touch.
- Crawl and hold your breath as much as possible to help reduce smoke inhalation during your escape.
- Meet at a designated outdoor location.
- Emphasize that no one should return to the premises if there is a fire.
- Notify the fire department from a neighbor's phone.
- Emphasize that no one should enter the premises if they hear sirens in the house.
- If you arrive at the premises and hear sirens, do not enter. Call for emergency assistance from a neighbor's phone.


Smoke and heat detector locations

Selecting a suitable location is critical to the operation of smoke alarms. *Figure 5* shows some typical floorplans with recommended smoke and heat detector locations. Use these location guidelines to optimize performance and reduce the chance of false alarms:

- Before mounting alarms, program (learn) them into memory and do a sensor test from the alarm's intended location to ensure good RF communication to the panel.
- Locate the alarm in environmentally controlled areas where the temperature range is between 40 and 100°F (5 and 38°C) and the humidity is between 0 and 90% noncondensing.
- Locate alarms away from ventilation sources that can prevent smoke from reaching the alarm.
- Locate ceiling mounted alarms in the center of the room or hallway, at least 4 in. (10 cm) away from any walls or partitions.
- Locate wall mounted alarms so the top of the alarm is 4 to 12 in. (10 to 31 cm) below the ceiling.
- In rooms with sloped, peaked, or gabled ceilings, locate alarms 3 ft. (0.9 m) down or away from the highest point of the ceiling.
- When mounting to suspended ceiling tile, the tile must be secured with the appropriate fasteners to prevent tile removal.

Note: Do not mount the alarm to the metal runners of suspended ceiling grids. The metal runners can draw the magnet's field away from the alarm's reed switch and cause a false tamper alarm.

Figure 5. Smoke detector locations



Your floorplan

Use the following guidelines when drawing your floorplan:

- Show all building levels.
- Show exits from each room (two exits per room are recommended).
- Show the location of all security system components.
- Show the location of any fire extinguishers

Sensor and module locations

Use *Table 13* and *Table 14* on page 48 to list your sensor and module locations.

Table 13. Sensor locations

Sensor number	Sensor name	Sensor type	Location
Example	Front door	Door/window sensor	Front door
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			

Table 13. Sensor locations (continued)

Sensor number	Sensor name	Sensor type	Location
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			

Table 14. X10 module locations

Unit #	Location
1	
2	
3	
4	
5	
6	
7	
8	

Unit #	Location
9	
10	
11	
12	
13	
14	
15	
16	

Access codes

Table 15. Access codes

Code description	Code
Master code	
User code 1	
User code 2	
User code 3	
User code 4	
User code 5	
User code 6	
User code 7	
User code 8	
Duress code	

Delays

Table 16. Delays

Delay	Time
Exit delay	
Entry delay	

Battery removal/disposal instructions








































This product contains one sealed, rechargeable NiMH (nickel metal hydride) battery pack. It is a maintenance-free, leakproof, long-life battery that should not be removed under normal circumstances. Because removing the battery may affect the product's configuration settings or trigger an alarm, only a qualified installer should remove the battery.

To remove the battery, do the following:

1. Make sure that your product settings allow you to open its cover without starting the tamper alarm.
2. Switch off the mains power.
3. Press the tabs at the top of the panel and swing cover/chassis assembly away from the back piece.
4. Disconnect the battery by unplugging the battery leads from the battery connector on the panel.
5. Unfasten the battery strap and remove the battery.

For proper recycling, dispose of all batteries as required by local ordinances or regulations. See the specifications for your product or contact technical support for information on replacement batteries.

Table 17. Simon XT system quick reference ^a

	Control panel	Remote touchpad	Keyfob	Telephone
Level 0: Subdisarm the system	Enter the master code while the system is disarmed.			1
Level 1: Disarm the system	 - <access_code>			1
Level 2: Stay	 - <access_code> (if required)			2
Level 3: Away	 - <access_code> (if required)		 - 	3
Activate no delay	 -  Appends <i>No Delay</i> to arming level text.	 - 		2 - 2
Activate latchkey	 - <access_code> (if required) - 	 - 	 -  - 	3 - 3
Activate panic alarm	Press Fire , Emergency , or Police twice within 3 sec. or hold it for 2 sec.	 +  Hold both for 3 sec.	 +  Hold both for 3 sec.	
Check system status				0
Toggle chime or special chime mode	Scroll to <i>Chime</i> or <i>Special Chime</i> , Enter , toggle <i>On/Off</i> , Enter .			
Bypass a sensor	 - <master_code> -  (scroll to sensor)			
Time-activated lights on/off	Scroll to <i>Light Schedules</i> , Enter , toggle <i>On/Off</i> , Enter .			
Sensor-activated lights on/off	Scroll to <i>Sensor Lights</i> , Enter , toggle <i>On/Off</i> , Enter .			
Specific light on	Press *, <unit_num>.	 - <unit_num>.		* - <unit_num>.
Specific light off	Press #, <unit_num>.	 - <unit_num>.		# - <unit_num>.
All lights on	To turn on all lights controlled by lamp modules, press * twice. The panel displays <i>All Lights On</i> .	 - 		* - *
All lights off	To turn off all lights controlled by lamp modules, press # twice. The panel displays <i>All Lights Off</i> .	 - 		# - #

a. A minus sign (-) between buttons means *press one then the next*; a plus sign (+) between buttons means *press both simultaneously*.

Index

A

AC power failure	21
access codes	30, 49
accidental alarms	13
alarm sirens	20
alarms	12
appliance module	3
appliance modules	2
arm doors and windows	10
arm motion sensors	10
arming levels	9

B

battery failure	22
bypass	12

C

chimes	13
clearing status	22
clock	27
code options	24
components	2
contrast	29
conventions	v

D

delays	49
door/window sensors	2
duress code	24, 31

E

emergency button	7
emergency planning	45
exit/entry delay	10

F

fail-to-communicate	22
features	9
fire button	7
firmware revision	29

floorplans	47
------------------	----

H

handheld touchpad	3, 4
housecode	37

K

keychain touchpad	See <i>keyfob</i>
keyfob	2, 3, 17

L

lamp module	3
lamp modules	2, 20
latchkey	14
latchkey time	32
LEDs	8
light control	13, 36
light schedules	36
lock button	17

M

master code	24, 30
menu navigation	25
menu structure	25
module locations	47
modules	3
motion sensor	2

P

panel controls	6
panel indicator lights	20
panel keys	7
panel piezo alarm	34
panel piezo beeps	34
panel voice	34
phone numbers	32
phones	15
piezo beeps	34
PIR motion sensor	2
police button	7
preface	v

program mode.....	30
programming	23

Q

quick exit	11
quick reference chart	51

R

restoration of power.....	22
revision	29
RF jam detected.....	22

S

safety terms and symbols	v
security menu	31
sensor failure	22
sensor locations	47
sensor low battery.....	22
sensor open	22
sensor tampered.....	22
sensors	3
shock sensor	3
silent exit	11
siren options	34
smoke and heat detector locations.....	46
smoke detector.....	2, 3
speaker volume	35
status	14

status beep volume	35
status beeps	21
system battery failure	22
system features	9
system limitations.....	44
system menu.....	24
system status.....	14
system tests.....	29

T

talking touchpad	3, 4
testing	39
<i>communication</i>	41
<i>sensors</i>	40
timers	32
touchpads.....	3, 16
trouble beeps	21
two-button pendant panic sensor.....	3
two-way talking touchpad.....	2, 16

U

unbypass	12
universal module	3
universal modules.....	2
unlock button.....	17
user codes	24, 30

V

voice chime	13
-------------------	----