

24/48/96 zone wire-free system operation

Arming	
Home:	Press 2 + code*
Away:	Press 3 + code*
Silent Arming:	Press 2 + code* + 5 for home Press 3 + code* + 5 for away
Disarming	Press 1 + code*
Bypass	To arm system while any door or window (protected by a contact sensor) is open: Press 2 + code* + # + code for home Press 3 + code* + # + code for away
Status/Alarm Memory	Press * + code* for short status report Press * + code* + * for long status report
Sensors	To identify which sensor activated the alarm follow the status/alarm memory instructions outlined above
Panic Button	Press the following buttons at the same time for 2 seconds: A + 1 for Police B + 4 for Emergency C + 7 for Fire
Should you activate a panic alarm in error please wait for our call and	

Should you activate a panic alarm in error please wait for our call and do not engage your phone line. If we are unable to confirm that the alarm is false the relevant emergency service will be dispatched and in some cases charges may apply.

Please ensure you close all exterior doors and windows before setting your alarm



Your safety. Our passion.