Simon XT Remote Access Card

How to gain remote access to the control panel:

- 1. Call the panel. (In most cases this is the same number as the regular phone.).
- 2. Let the phone ring twice, then hang up.
- 3. Wait between 10 and 15 seconds, then call the panel again.

The panel will answer ("System on Enter Access code").

- 1. Press * and enter your Access code. You will hear a beep.
- 2. Proceed with system commands.
- 3. When finished using the remote access please press 9.
- * If 1. and 2. do not connect to panel call again, let the phone ring 12 times and the panel will answer.

Phone Commands

Disarm the System

Arm to Home

Arm to Away

Check Status

Turn Light On

Turn Light Off

Turn All Lights On

Turn All Lights Off

Hang Up



0818 753 753 www.phonewatch.ie



